

**HARLEY DAVIDSON SRINGER
INSTALLATION INSTRUCTIONS
You Will Need Rubber Mount
Shock Absorber (Part # 69123-92)**

TRUMPET INSTALLATION

Remove seat.

Remove driving light switch located beside the choke. TIP: Loosen the switch by turning it from the back of the bracket. This will help remove the nut located on the front.

Cut all three (3) wires from switch. Crimp all three (3) wires together. Install rubber mount shock absorber in the hole where you removed the switch.

Install trumpet assembly loosely. Use tooth washer, air horn, tooth washer, then acorn nut provided with shock absorber.

Remove existing positive wire from original stock horn. Extend this wire to run under and to the side of the gas tank and under the seat. This wire will connect to terminal 85 of the relay.

Route air hose behind spark plug wires, under gas tank and to the trumpet assembly. Connect hose to Y of the trumpet assembly. The rear of the hose routes along the frame on top of oil tank, behind swing arm to the top of the left saddlebag.

COMPRESSOR INSTALLATION

The compressor will be located to the top left side of the left saddlebag. Drill a 5/16 inch hole to mount the compressor. Use a 5/16" bolt to mount. The ground wire of the compressor will be attached to the left hand side mounting bolt of the saddlebag. Underneath, where the compressor is mounted, drill a 3/8" hole for the air hose to run thru.

Drill a 1/8" hole for the positive wire of the compressor to run thru. Connect positive wire of compressor to terminal 87 of the relay. Terminal 86 will ground to the frame. Terminal 30 will go to the battery positive.

The relay will lay in front of the battery, under the seat.

Re-install seat and tighten the trumpet assembly to a horizontal level position.

FINAL STEPS

Make sure you route the air hose and wires away from the exhaust and as much out of sight as possible.

COMPRESSOR MUST STAY DRY. NOT MOUNTING IT IN SUGGESTED LOCATIONS WILL VOID THE WARRANTY.

HORNS ARE MADE TO BE BLOWN. BLOW THEM EACH TIME YOU GET ON YOUR BIKE. FAILURE TO DO SO WILL RESULT IN THE TRUMPETS STICKING.

BJ Specialties

Air Horn Wiring Diagram

